


LENZA™

Lenza™ is the latest wall innovation from Keystone Hardscapes. With its clean, contemporary design, smooth finish, and chamfered edges, it's the perfect choice for both structural and decorative wall applications. Lenza retaining walls utilize the DOM pins. Freestanding Lenza structures are glued in-place and the pins are optional.



Lenza™ Wall Block



DOM - Alignment Pins

Before specifying a specific product, please confirm availability with your local Keystone Hardscapes producer.

PRODUCT	DIMENSIONS		
	Width	Length	Height
Lenza™ Wall Block	9" 228.6 mm	18" 457.2 mm	5" 127 mm

FEATURES & BENEFITS

Perfect for:

- Decorative walls, retaining walls, fire pits, outdoor kitchen and grill stations.

Ease of Installation

- Retaining walls utilize the DOM alignment pins.
- Freestanding structures are glued in-place and the pins are optional.

Aesthetics

- The vertical edges and bottom of the unit is chamfered for a clean distinctive look.

Note: Unit color, dimensions, weight, and availability varies by manufacturer.



OUTDOOR
LIVING



FREESTANDING
WALLS

RETAINING WALL INSTALLATION INSTRUCTIONS

STEP 1: Layout - Stake out the wall's placement according to lines and grades on approved plans. Excavate for the leveling pad to the lines and grades shown. Excavate soil to a dimension behind the wall for placement of grid and reinforced soils.

STEP 2: Leveling Pad - The leveling pad consists of a crushed aggregate compactible base material. The pad must extend a minimum six (6) inches in front and behind the first unit, and be a minimum six (6) inches in depth. Compact the aggregate and check top elevation for level.


STEP 3: Base Course - For gravity walls, one complete course of units must be buried. For taller reinforced walls, additional courses of block may need to be buried; consult the approved wall plans.

Place a string line along the back of the units to align the wall units. Begin laying unit at the lowest elevation of the wall. Place wall units flat on the leveling pad. Place the units side-by-side, flush against each other, and in full contact with the leveling pad. Level the unit front-to-back and side-to-side. Check the units for proper horizontal alignment.

STEP 4: Wall Construction - Clean any debris off the top of the units. Units should be placed in the wall with the mid-point of the unit above over the vertical joint between the two units below (running bond). Push each unit forward as far as possible to ensure pin engagement and the correct setback. Backfill with drainage aggregate directly behind the unit to a depth of 24" from the face of the wall.

STEP 5: Drainage - Place a perforated drain pipe at the base of the drainage aggregate. Daylight or direct the drain to an area lower than the lowest drain elevation in the wall. Additional drainage design may be required.

STEP 6: Install Fill and Compaction - Place the drainage aggregate as directed. Fill behind the drainage aggregate with soil meeting design parameters. Place and compact the backfill material before the next course is laid. Hand-operated equipment should be used within three (3) feet of the wall. Avoid driving heavy equipment within three (3) feet of the wall units. Place reinforced backfill soil behind the drainage aggregate in maximum 6-8" lifts and compact to a minimum of 95% standard Proctor density with the appropriate compaction equipment.



STEP 7: Geogrid Reinforcement Placement - Check approved wall construction plan for grid type, strength, lengths and elevations. Measure and cut the reinforcement grid to the design length in the plans. The design strength direction of the geogrid shall be laid perpendicular to the wall. Place the front edge of the geogrid on the designated course a maximum of one (1) inch from the face of the unit. Apply the next course of units to secure it in place. Pull the reinforcement taut and secure in place. A minimum of six (6) inches of backfill over the grid is required prior to vehicular operation.

STEP 8: Finish Grade and Surface Drainage - Protect your wall from water damage and erosion with a finished grade to provide positive drainage away from the wall at the top and bottom of the wall structure during construction. To minimize infiltration of water into the top of the backfill area of the wall, place a minimum of eight (8) inches of soil with low permeability (clay or similar materials) over the drainage aggregate and backfill soils at the top of the wall.

NOTE: Colors are shown as accurately as possible in brochures and samples, but due to the nature of the product, regional color differ.

Free Standing Structures: Each course of free standing structures must be glued with an approved exterior concrete adhesive. The use of pins is optional.

Complete installation and specification details are available by contacting your Keystone Hardscapes Sales Representative.



keystonehardscapes.com